

Installation Instructions

CONTENTS:	(8) 5/16-18 x 1-1/4" HEX BOLT	(2) H-076 M8 HEX BOLT
	(28) 5/16" FLAT WASHER	(2) H-075 M8 HEX NUT
	(16) 5/16" LOCK WASHER	(1) H-461 FRONT BRACKET LEFT
	(12) 5/16" HEX NUT	(1) H-460 FRONT BRACKET RIGHT
	(2) 5/16" U-Bolt	(1) H-385 REAR BRACKET LEFT
		(1) H-386 REAR BRACKET RIGHT

1. Driver side front, Install the supplied 5/16 U-bolt in the body mount tab. Install the front left bracket and secure with a 5/16-18 hex nut, lock washer and two flat washer on both ends. Hand tighten only.
2. Driver side rear, Install bracket using the lower set of slots to the factory M8 bolt and Hex nut. Secure rear left bracket with an M8 hex bolt and a M8 hex nut. Tighten by hand only.
3. Bolt the tube to the mounting brackets with two 5/16-18 hex bolts, lock washers, flat washers and 5/16-18 hex nuts. Snug the bolts, then check the alignment of the tube against the rocker panel.
4. Make any necessary adjustments, then tighten M8 and 5/16-18 fasteners to 12 ft lbs. each.
5. Repeat steps on opposite side of vehicle.

