

## Installation Instructions

### CONTENTS:

(12) 5/16-18 x 1-1/4" HEX BOLT  
(28) 5/16" FLAT WASHER  
(16) 5/16" LOCK WASHER  
(12) 5/16" HEX NUT  
(2) H-076 M8 HEX BOLT

(2) H-075 M8 HEX NUT  
(1) H-383 FRONT BRACKET LEFT  
(1) H-384 FRONT BRACKET RIGHT  
(1) H-385 REAR BRACKET LEFT  
(1) H-386 REAR BRACKET RIGHT

1. Driver side front, Install the supplied 5/16-18 bolt, lock washer and flat washer using a socket wrench extension. Use the extension to reach the top hole in the front body mount tab. Install the front left bracket and secure with a 5/16-18 hex nut and flat washer. Install second 5/16-18 hex bolt in bottom hole. Hand tighten only.
2. Driver side rear, Install bracket using the Upper set of slots to the factory M8 bolt and Hex nut. Secure rear left bracket with an M8 hex bolt and a M8 hex nut. Tighten by hand only.
3. Bolt the tube to the mounting brackets with two 5/16-18 hex bolts, lock washers, flat washers and 5/16-18 hex nuts. Snug the bolts, then check the alignment of the tube against the rocker panel.
4. Make any necessary adjustments, then tighten M8 and 5/16-18 fasteners to 12 ft lbs. each.
5. Repeat steps on opposite side of vehicle.

