

## Installation Instructions

<b>CONTENTS:</b>	(2) STEP TUBES	(12) 3/8" FLAT WASHERS
	(4) MOUNTING BRACKETS H-375	(8) 5/16-18 HEX BOLTS
	(12) H-076 M8 HEXS BOLT	(8) 5/16" LOCK WASHERS
	(12) 3/8" LOCK WASHERS	(8) 5/16-18 HEX NUTS
		(16) 5/16" FLAT WASHERS

1. Install the supplied M8-1.25 x 30mm bolts through a lock washer, flat washer, mounting bracket and into the body panel.( Drivers side Front ) Snug by hand.
2. Install the supplied M8-1.25 x 30mm bolts through a lock washer, flat washer, mounting bracket and into the body panel. ( Drivers side Rear ) Snug by hand.
3. Bolt the tube to the mounting brackets with two 5/16-18 hex bolts, lock washers, flat washers and 5/16-18 hex nuts. Snug the bolts, then check the alignment of the tube against the rocker panel.
4. Make any necessary adjustments, then tighten M8 and 5/16-18 fasteners to 12 ft lbs each.
5. Repeat steps on opposite side of vehicle.

